



Kompatibilitetsliste for Inkjet Printere

Opdateret den 7. august 2013



Sigurd Rasmussen A/S

Hvidsværmervej 156 - 2610 Rødovre
www.sigurdrasmussen.dk - www.inkjetspecial.dk

36 46 88 44



Maskinnavn	Modelnummer	Gruppenummer
Brother	1000 LC	400
Brother	110 DCP C	260
Brother	1100 LC Black	428
Brother	1100 LC Cyan	428
Brother	1100 LC HYBk	428
Brother	1100 LC HYC	428
Brother	1100 LC HYM	428
Brother	1100 LC HYY	428
Brother	1100 LC Magenta	428
Brother	1100 LC Yellow	428
Brother	115 DCP C	260
Brother	117 DCP C	260
Brother	1220 LC Bk/C/M/Y	931S/R/B/G lig med 929
Brother	1240 LC Bk/C/M/Y	929S/R/B/G
Brother	125 DCPJ	450
Brother	1280 Bk/M/C/Y	930S/R/B/G
Brother	130 DCP C	400
Brother	135 DCP C	410
Brother	1360 Fax	400
Brother	140 DCP J	450
Brother	145 DCP C	406
Brother	1460 Fax	406
Brother	150 DCP C	410
Brother	153 DCP C	410
Brother	157 DCP C	410
Brother	165 DCP C	406
Brother	1820 FAX CN	260
Brother	1840 FAX C	260
Brother	210 MFC C	260
Brother	215 MFC C	260
Brother	230 MFC C	410
Brother	235 MFC C	410
Brother	240 MFC C	400
Brother	2440 FAX C	260
Brother	2480 FAX C	400
Brother	250 MFC C	406
Brother	260 MFC C	410
Brother	290 MFC C	406
Brother	310 DCP CN	260
Brother	315 DCP CN	260
Brother	315 DCP W	450
Brother	3240 MFC C	260
Brother	330 DCP C	400
Brother	3340 MFC C + CN	260
Brother	3360 MFC C	400
Brother	340 DCP CW All in one	260
Brother	350 DCP C	400
Brother	353 DCP C	400
Brother	357 DCP C	400
Brother	375 DCP CW	406
Brother	385 DCP C	428
Brother	4020 DCP	400
Brother	410 MFC CN	260
Brother	410 MFCJ + W	450
Brother	415 MFCJ W	450
Brother	425 MFC CN	260
Brother	430 MFC JW	929S/R/B/G
Brother	440 MFC CN	400
Brother	465 MFC CN	400



Maskinnavn	Modelnummer	Gruppenummer
Brother	4820 MFC	400
Brother	51 LC	400
Brother	515 DCPJ + W	450
Brother	525 DCP J W	929/931S/R/B/G
Brother	540 DCP CN	400
Brother	5440 MFC CN	260
Brother	5490 MFC CN	428
Brother	560 DCP CN	400
Brother	5840 MFC CN	260
Brother	585 DCP C	428
Brother	5860 MFC CN	400
Brother	5890 MFC CH	428
Brother	5910 MFC J DW	929/930S/R/B/G
Brother	61 LC	406
Brother	620 MFC CN	260
Brother	625 MFC DW	929/931S/R/B/G
Brother	6490 DCP CW	428
Brother	6490 MFC CW	428
Brother	6510 MFC 3 DW	929/930S/R/B/G
Brother	665 MFC CW	400
Brother	6690 DCP CW	428
Brother	6690 MFC CDW	428
Brother	6710 MFC 3 DW	929/930S/R/B/G
Brother	6890 MFC CDW	428
Brother	6910 MFC 3 DW	929/930S/R/B/G
Brother	725 DCP J W	929S/R/B/G
Brother	750 DCP CW	400
Brother	770 DCP CW	400
Brother	790 MFC CW	428
Brother	820 MFC CW All in one	260
Brother	825 MFC J DW	929/931S/R/B/G
Brother	845 MFC CW	400
Brother	885 MFC CW	400
Brother	900 LC	260
Brother	925 DCP J DW	929/931S/R/B/G
Brother	970 LC	410
Brother	980 LC Black	406S
Brother	980 LC Cyan	406B
Brother	980 LC Magenta	406R
Brother	980 LC yellow	406G
Brother	985 LC Black	450
Brother	985 LC Cyan	450
Brother	985 LC Red	450
Brother	985 LC Yellow	450
Brother	990 MFC CW	428



Maskinnavn	Modelnummer	Gruppennummer
Canon	05 BC	907C
Canon	06 BC	907F
Canon	1000 IP Pixma	944S/C
Canon	110 Pixma MP	944S/C
Canon	1200 JX Fax	699S/SM
Canon	1200 Pixma IP	699SM/CM
Canon	130 Pixma MP	944S/C
Canon	1300 Pixma IP	699SM/CM
Canon	140 Pixma MP	698S/C/699SM/CM
Canon	150 Pixma MP	699S/SM/C/CM
Canon	1500 Pixma IP	944S/C
Canon	160 Pixma IP	699S/SM/C/CM
Canon	1600 Pixma IP	699SM/CM
Canon	170 Pixma MP	699S/SM/C/CM
Canon	1700 Pixma IP	699SM/CM
Canon	180 Pixma IP	699S/SM/C/CM
Canon	1800 Pixma IP	699SM/CM
Canon	1880 Pixma IP	699S/SM/C/CM
Canon	190 MPC	944S/C
Canon	190 Pixma MP	699S/SM/C/CM
Canon	1980 Pixma IP	699SM/CM
Canon	200 Fax JX	699SM/S/C/CM
Canon	200 S + X + MPC Smartbase	944PC/S/C
Canon	2000 Pixma IP	944S/C
Canon	210 Pixma MP	698S/C/699SM/CM
Canon	2100 BJC	900
Canon	2150 Pixma MG	654SM/S/CM/C
Canon	2155 Pixma MG	654SM/S/CM/C
Canon	220 Pixma MP	698S/C/699SM/CM
Canon	2200 Pixma IP	699S/C + Mini
Canon	2250 Pixma MG	654SM/S/CM/C
Canon	2255 Pixma MG	654SM/S/CM/C
Canon	24 BC	944PC
Canon	24 BCI Bk	944S
Canon	24 BCI Color	944C
Canon	250 I	944S/C
Canon	250 Pixma MP	523
Canon	2500 Pixma IP	698S/C/699SM/CM
Canon	260 Pixma MPF	523
Canon	2600 Pixma IP	698S/C/699SM/CM
Canon	270 Pixma MP	523
Canon	2700 Pixma IP	523
Canon	280 Pixma MP	523
Canon	3 BCI Bk	957S
Canon	3 BCI Cyan	957B
Canon	3 BCI Magenta	957 R
Canon	3 BCI Photobk	957FS
Canon	3 BCI Photocyan	957FB
Canon	3 BCI Photomagenta	957 FR
Canon	3 BCI Yellow	957 G
Canon	3 BX	953
Canon	3 CJ A	921
Canon	300 Pixma MX	699S/SM/C/CM
Canon	300 S	944PC/S/C
Canon	3000 Pixma IP	957S/958R/B/G
Canon	310 Bubblejet I	944S/C
Canon	310 Pixma MX	699S/SM/C/CM
Canon	3150 Pixma MG	654SM/S/CM/C
Canon	320 Bubblejet I	944S/C



Maskinnavn	Modelnummer	Gruppenummer
Canon	320 Pixma MX	523
Canon	320 Pixus I	944S/C
Canon	3250 Pixma MG	654SM/S/CM/C
Canon	330 Pixma MX	523
Canon	330 S	944S/C
Canon	3300 Pixma IP	275R/B/G/276S
Canon	340 Pixma MP	523
Canon	350 I	944S/C
Canon	350 Pixma MP	523
Canon	3500 Pixma IP	275R/B/G/276S
Canon	360 MPC Smartbase	944S/C
Canon	360 Pixma MX	523
Canon	3600 Pixma IP	579S/580S/R/B/G
Canon	37 PG	698S
Canon	370 MPC Smartbase	944S/C
Canon	375 Pixma MX	654SM/S/CM/C
Canon	38 CL	698C
Canon	390 MP Smartbase	944S/C
Canon	40 PG	699Smini
Canon	4000 Pixma IP	957S/958S/R/B/G/FR/FB
Canon	4000 Pixma IP R	957S/958S/R/B/GFR/FB
Canon	4000 Pixma IX	275R/B/G/276S
Canon	41 CL	699Cmini
Canon	410 Pixma MX	523
Canon	4150 Pixma MG	654SM/S/CM/C
Canon	420 Pixma MX	523
Canon	4200 BJC	900
Canon	4200 Pixma IP	276S/275S/B/R/G
Canon	4250 Pixma MG	654SM/S/CM/C
Canon	4300 Pixma IP	275S/R/B/G/276S
Canon	435 Pixma MX	654SM/S/CM/C
Canon	450 I	944S/C
Canon	450 Pixma MP	699S/C + Mini
Canon	4500 Pixma IP	275S/R/B/G/276S
Canon	455 I Bubblejet	944S/C
Canon	460 Pixma MP	699S/SM/C/CM
Canon	4600 Pixma IP	579S/580S/R/B/G
Canon	470 I + D	944S/C
Canon	470 Pixma MP	698S/C/699SM/CM
Canon	4700 Pixma IP	579S/580S/R/B/G
Canon	475 I Bubblejet + D	944S/C
Canon	480 I Bubblejet + D	944S/C
Canon	480 Pixma MP	523
Canon	4850 Pixma IP	650S/651R/B/G/FS
Canon	490 Bubblejet I + D	944S/C
Canon	490 Pixma MP	523
Canon	495 Pixma MP	523
Canon	4950 Pixma IP	650S/651R/B/G/FS
Canon	5 PGI Bk	276S nyt nr
Canon	50 PG	699S
Canon	500 JX FAX	699S/SM
Canon	500 Pixma MP	276S/275S/B/R/G
Canon	5000 Pixma IP	957S/958S/R/B/G
Canon	51 CL	699C
Canon	510 PG 9ml sort	523
Canon	510 Pixma MP	276S/275R/B/G
Canon	5100 Pixma MG	650S/651S/R/B/G
Canon	511 CL 9 ml 3-farvet	523
Canon	512 PG 15 ml sort	523



Maskinnavn	Modelnummer	Gruppenummer
Canon	513 CL 13 ml 3-farvet	523
Canon	515 Pixma MX	654SM/S/CM/C
Canon	5150 Pixma MG	650S/651R/B/G/FS
Canon	52 BP D	921
Canon	52 CL Photocolor	699F
Canon	520 PGI	579S
Canon	520 Pixma MP	276S/275S/R/B/G
Canon	5200 Pixma IP	276S/275S/B/R/G
Canon	5200 Pixma IP R	276S/275S/B/R/G
Canon	521 CLI BK	580S
Canon	521 CLI Cyan	580B
Canon	521 CLI GY	581Grå
Canon	521 CLI Magenta	580R
Canon	521 CLI Yellow	580G
Canon	525 CLI BK	650S
Canon	5250 Pixma MG	650S/651R/B/G/FS
Canon	526 CLI Cyan	651B
Canon	526 CLI Grey	651Grå
Canon	526 CLI Magenta	651R
Canon	526 CLI PBK	651FS
Canon	526 CLI Yellow	651G
Canon	530 MP Pixma	276S/275B/R/G
Canon	5300 Pixma IP	275S/R/B/G/276S
Canon	5350 Pixma MG	650S/651R/B/G/FS
Canon	540 Pixma MP	579S/580S/R/B/G
Canon	5450 Pixma MG	665S/664C/M/G/Grå
Canon	55 BJC	951/952/799
Canon	550 Pixma MP	579S/580S/R/B/G
Canon	551 CLI	664M/664R/B/G/Grå
Canon	551 PGI	665M/665S
Canon	560 i Bubblejet	957S/958R/B/G
Canon	560 Pixma MP	579S/580S/R/B/G
Canon	6 BCI BK	958S
Canon	6 BCI Cyan	958B
Canon	6 BCI Green	958 Grøn
Canon	6 BCI Magenta	958R
Canon	6 BCI Photocyan	958FB
Canon	6 BCI Photomagenta	958FR
Canon	6 BCI Red	958 Nyrod
Canon	6 BCI Yellow	958G
Canon	600 MP Pixma MP	275S/B/R/G/276S
Canon	6000 Pixma IP	958S/R/B/G/FR/FB
Canon	610 Pixma IP + MP	275S/R/B/G/276S
Canon	6150 Pixma MG	650S/651R/B/G/GRÅ/FS
Canon	620 Pixma MP	579S/580S/R/B/G
Canon	6210 Pixma IP D	699C/CM/FP
Canon	6220 Pixma IP D	699C/CM/FP
Canon	6250 Pixma MG	650S/651R/B/G/FS/Grå
Canon	630 Pixma MP	579S/580S/R/B/G
Canon	6350 Pixma MG	665S/664C/M/G/Grå
Canon	640 Pixma MP	579S/580S/R/B/G
Canon	6550 Pixma IX	650S/651R/B/G/FS
Canon	6600 Pixma IP	275S/B/R/G/FB/FR
Canon	6700 Pixma IP D	275S/R/B/G/FB/FR
Canon	7 PGI	596S
Canon	70 I	938S/C/940S
Canon	700 Pixma MX	276S/275S/R/B/G
Canon	7250 Pixma MG	665/664R/B/G/Grå
Canon	750 Pixma MP	957S/958S/R/B/G



Maskinnavn	Modelnummer	Gruppenummer
Canon	760 Pixma MP	958S/R/B/G/FR/FB/NYRØD/GRØN
Canon	780 Pixma MP	957S/958S/R/B/G
Canon	8 CLI BK	275S
Canon	8 CLI Cyan	275B
Canon	8 CLI Green	275Grøn
Canon	8 CLI Magenta	275R
Canon	8 CLI PC	275FB
Canon	8 CLI PM	275FR
Canon	8 CLI Red	275NyRød
Canon	8 CLI Yellow	275G
Canon	80 I	938S/C/940S
Canon	800 Pixma MP	276S/275S/B/R/G
Canon	800 S	958S/R/B/G/FS/FR/FB
Canon	810 Pixma MP	275S/R/B/G/276S
Canon	8150 Pixma MG	650S/651R/B/G/GRÅ/FS
Canon	820 S + D	958S/R/B/G/FS/FR/FB
Canon	8200 BJC FOTO	958S/R/B/G/FR/FB
Canon	8250 Pixma MG	650S/651R/B/G/FS/Grå
Canon	830 Pixma MP	276S/275S/B/R/G
Canon	830 S + D	958S/R/B/G/FS/FR/FB
Canon	850 MX	650S/651S/R/B/G
Canon	850 Pixma MX	275S/276S/R/B/G
Canon	8500 Pixma IP	958S/R/B/G/FR/FB/NYRØD/GRØN
Canon	860 Pixma MX	579S/580S/R/B/G
Canon	865 I Bubblejet	957S/958S/R/B/G/FS/FR/FB
Canon	870 Pixma MX	579S/580S/R/B/G
Canon	884 MX	650S/651S/R/B/G
Canon	885 MX	650S/651S/R/B/G
Canon	895MX	650S/651S/R/B/G
Canon	90 Pixma IP	938S/940C
Canon	900 S + I	958S/R/B/G/FS/FR/FB
Canon	9000 Pixma Pro	275S/B/R/G/FB/FR
Canon	9000 S	958S/R/B/G/FR/FB
Canon	905 I D	958S/R/B/G/FS/FR/FB
Canon	9100 I	958S/R/B/G/FR/FB
Canon	925 Pixma MX	665/664S/R/B/G/Grå
Canon	950 Bubblejet I	958S/R/B/G/FS/FR/FB
Canon	960 I	958S/R/B/G/FS/FR/FB
Canon	965 I	958S/R/B/G/FS/FR/FB
Canon	970 Pixma MP	275S/R/B/G/276S
Canon	980 Pixma MP	579S/580S/R/B/G/581
Canon	990 I	958S/R/B/G/FS/FR/FB
Canon	990 Pixma MP	579S/580S/R/B/G/581
Canon	9950 Pixma I	958S/R/B/G/FR/FB/NYRØD/GRØN



Maskinnavn	Modelnummer	Gruppenummer
Epson	100 Stylus SX	279
Epson	102 XP	748
Epson	105 Stylus SX	279
Epson	110 Stylus SX	279
Epson	115 Stylus SX	279
Epson	120 Stylus SX	279
Epson	125 Stylus SX	82S/R/B/G
Epson	1281 T	82S
Epson	1282 T	82B
Epson	1283 T	82R
Epson	1284 T	82G
Epson	1285 T	82 4pack
Epson	1291 T	83S
Epson	1292 T	83B
Epson	1293 T	83R
Epson	1294 T	83G
Epson	1295 T	83 4pack
Epson	130 Stylus SX	82S/R/B/G
Epson	130 T	84S/R/B/G
Epson	1301 T	84S
Epson	1302 T	84B
Epson	1303 T	84R
Epson	1304 T	84G
Epson	18 T Bk/M/C/Y	748
Epson	1801 T	748
Epson	1802 T	748RM
Epson	1803 T	748BM
Epson	1804 T	748GM
Epson	1811 T	748S
Epson	1812 T	748R
Epson	1813 T	748B
Epson	1814 T	748G
Epson	200 Stylus SX	279
Epson	202 XP	748
Epson	205 Stylus SX	279
Epson	205 XP	748
Epson	30 Stylus BX SF	82S/R/B/G + 83S/R/B/G
Epson	30 XP	748
Epson	300 Stylus Office BX F	279
Epson	302 XP	748
Epson	305 Stylus BX SF	83S/R/B/G
Epson	305 Stylus Office BX F + FW	82S/R/B/G + 83/84S/R/B/G
Epson	305 XP	748
Epson	310 Stylus SX	82S/R/B/G
Epson	320 Stylus BX FW	83S/R/B/G
Epson	320 Stylus Office BX FW	83S/R/B/G + 84S/R/B/G
Epson	40 Stylus Office B W	279
Epson	400 Stylus SX	279
Epson	402 XP	748
Epson	405 Stylus SX	279
Epson	405 Stylus SX WFI	279
Epson	405 XP + HW	748
Epson	42 Stylus Office B WD	83S/R/B/G + 84S/R/B/G
Epson	420 Stylus SX W	82S/R/B/G + 83S/R/B/G
Epson	425 Stylus SX W	82S/R/B/G + 83S/R/B/G
Epson	4300 Stylus CX AIO	279
Epson	435 Stylus Photo SX W	82/83S/R/B/G
Epson	4400 Stylus DX	279
Epson	445 Stylus SX W	82S/R/B/G + 83S/R/B/G
Epson	4450 Stylus DX	279



Maskinnavn	Modelnummer	Gruppenummer
Epson	5000 Stylus DX	279
Epson	5050 Stylus DX	279
Epson	525 Stylus SX WD + Office	83S/R/B/G + 84S/R/B/G
Epson	535 Stylus Office BX WD	83/84S/R/B/G
Epson	6000 Stylus DX	279
Epson	6050 Stylus DX	279
Epson	6070 Stylus DX	279
Epson	620 Stylus SX FW	83S/R/B/G + 84S/R/B/G
Epson	625 Stylus BX FWD	83S/R/B/G + 84S/R/B/G
Epson	625 Stylus Office BX FWD	83S/R/B/G + 84S/R/B/G
Epson	635 Stylus Office BX FW	83/84S/R/B/G
Epson	6900 Stylus CX	279
Epson	7000 Stylus DX F	279
Epson	7015 Workforce WF	83/84S/R/B/G
Epson	7300 Stylus DX	279
Epson	7400 Stylus DX	279
Epson	7450 Stylus DX	279
Epson	7515 Workforce WF	83S/R/B/G
Epson	7575 Workforce WF	83/84S/R/B/G
Epson	78 Stylus D	279
Epson	8400 Stylus DX	279
Epson	8450 Stylus DX	279
Epson	92 Stylus D	279
Epson	925 Stylus Office BX WD	83/84S/R/B/G
Epson	935 Stylus Office FWD	83/84S/R/B/G
Epson	9400 Stylus DX	279



Maskinnavn	Modelnummer	Gruppenummer
HP	010 Photosmart B All in one	540S/R/B/G
HP	100 ENVY AIO	534S/C
HP	100 Photosmart	573C/573FP
HP	1000 Deskjet CH340B	551S/C
HP	1000 Deskjet J110	551S/C
HP	1000 Photosmart + P	927S/992C
HP	1050 Deskjet AIO	551S/C
HP	109 Photosmart B AIO	540S/R/B/G/FS
HP	110 Photosmart BA	540S/R/B/G/FS
HP	1100 Deskjet C	927S/C
HP	1100 Photosmart P	927S/992C
HP	1100 PSC	544S/573C
HP	1110 PSC	544S/573C
HP	1115 Photosmart	927S/992C
HP	1120 Deskjet C	927S/928C
HP	1125 Deskjet C	927S/928C
HP	1150 Officejet C Pro	927S/C
HP	1170 Officejet C Pro	927S/928C
HP	1175 Officejet C Pro	927S/928C
HP	1200 PSC	544S/573C
HP	1205 PSC All in one	544S/573C
HP	1209 PSC All in one	544S/573C
HP	1210 PSC XCI	544S/573C
HP	1213 PSC All in one	544S/573C
HP	1215 Photosmart	927S/992C
HP	1215 PSC All in one	544S/573C
HP	1216PSC	544S/573C
HP	1217 PSC	544S/573C
HP	1218 Photosmart	927S/992C
HP	1218 PSC	544S/573C
HP	1219 PSC All in one	544S/573C
HP	1220 Deskjet C	927S/992C
HP	1240 Fax	544S/573C
HP	1250 Fax XI	586S/587C
HP	1280 Deskjet	927S/992C
HP	130 Photosmart	573C/F
HP	1300 PSC	544S/573C
HP	1310 PSC All in one	544S/573C
HP	1311 Deskjet D	586S/587C
HP	1315 Photosmart	927S/992C
HP	1315 PSC All in one	544S/573C
HP	1317 Photosmart	927S/992C
HP	1317 PSC All in one	544S/573C
HP	1320 Deskjet D	586S/587C
HP	1330 Deskjet D	586S/587C
HP	1340 PSC All in one	544S/573C
HP	1341 Deskjet D	586S/587C
HP	1350 PSC All in one	544S/573C
HP	1355 PSC All in one	544S/573C
HP	1360 Deskjet D	586S/587C
HP	1368 Deskjet D	586S/587C
HP	140 CQ B Photosmart E ST	540S/R/B/G/FS
HP	1401 PSC AIO	586S/587C
HP	1402 PSC All in one	586S/587C
HP	1403 PSC AIO	586S/587C
HP	1406 PSC AIO	586S/587C
HP	1408 PSC AIO	586S/587C
HP	1410 PSC	586S/587C



Maskinnavn	Modelnummer	Gruppenummer
HP	1415 PSC AIO	586S/587C
HP	1417 PSC	586S/587C
HP	1420 Deskjet D	586S/587C
HP	1430 Deskjet D	586S/587C
HP	1445 Deskjet D	586S/587C
HP	145 Photosmart	573C/574
HP	1455 Deskjet D	586S/587C
HP	1460 Deskjet D	586S/587C
HP	15 NO	993S
HP	1507 PSC	285S/290C
HP	1510 PSC +S + XI	286S/291C
HP	1560 Deskjet D	586S/587C
HP	1600 PSC All in one	286S/292C
HP	1610 PSC All in one	286S/292C
HP	1660 Deskjet D AIO	534S/C
HP	17 NO	572C
HP	1823 C A + G + D	928C
HP	2000 Deskjet J210	551S/C
HP	2050 Deskjet AIO	551S/C
HP	2054 Deskjet A10 + A	551S/C
HP	209 Photosmart B C Plus B	540S/R/B/G/FS
HP	21 NO	586S
HP	210 Photosmart B + E AIO	540S/R/B/G/FS
HP	2100 PSC	544S/573C
HP	2105 PSC	544S/573C
HP	2108 PSC + V + XI	544S/573C
HP	2110 Deskjet F AIO	586S/587C
HP	2110 PSC	544S/573C
HP	2115 PSC	544S/573C
HP	2120 Deskjet F AIO	586S/587C
HP	2128 Deskjet F AIO	586S/587C
HP	2140 Deskjet F AIO	586S/587C
HP	2149 Deskjet F AIO	586S/587C
HP	2150 Officejet PSC	544S/573C
HP	2170 PSC	544S/573C
HP	2175 PSC	544S/573C
HP	2180 Deskjet F AIO	586S/587C
HP	2185 Deskjet F AIO	586S/587C
HP	2187 Deskjet F AIO	586S/587C
HP	2188 Deskjet F AIO	586S/587C
HP	22 NO	587C
HP	2200 Deskjet F	586S/587C
HP	2200 PSC	544S/573C
HP	2210 Officejet PSC	544S/573C
HP	2275 Deskjet AIO	586S/587C
HP	2276 Deskjet AIO	586S/587C
HP	2280 Deskjet AIO	586S/587C
HP	23 NO	928C
HP	2310 PSC All in one	544S/573C
HP	2320 Deskjet D	586S/587C
HP	2330 Deskjet D	586S/587C
HP	2345 Deskjet D	586S/587C
HP	2350 PSC All in one	286S/292C
HP	2352 PSC	286S/292C
HP	2353 PSC	286S/292C
HP	2355 PSC + V + XI	286S/292C
HP	2357 PSC All in one	286S/292C
HP	2358 PSC All in one	286S/292C



Maskinnavn	Modelnummer	Gruppenummer
HP	2360 Deskjet D	586S/587C
HP	2368 Deskjet D	586S/587C
HP	2400 Deskjet D	586S/587C
HP	2400 Deskjet F	534S/C
HP	2400 PSC	544S/573C
HP	2405 PSC	544S/573C
HP	2410 PSC All in one	544S/573C
HP	2420 Deskjet F AIO	534S/C
HP	2420 PSC V + XI	544S/573C
HP	2445 CN B	540S/R/B/G
HP	245 Photosmart	573C/F/502
HP	2460 Deskjet D	586S/587C
HP	2468 Deskjet D	586S/587C
HP	2480 Deskjet F AIO	534S/C
HP	2492 Deskjet F AIO	534S/C
HP	2500 Deskjet C + CXI	360S/R/B/G
HP	2500 Deskjet D	534S/C
HP	2500 PSC All in one	544S/573C
HP	2510 Deskjet All in one	551S/C
HP	2510 PSC	544S/573C
HP	2560 Deskjet D	534S/C
HP	2570 Photosmart AIO	284S/286S/291C
HP	2575 Photosmart	284S/288S/292C
HP	2610 Photosmart + PSC XI	288S/292C
HP	2613 Photosmart	288S/292C
HP	2660 Deskjet D	534S/C
HP	27 NO	324S
HP	2710 Photosmart	288S/292C
HP	2713 Photosmart	288S/292C
HP	279 CB E	917S
HP	28 NO	325C
HP	280 CB E	917B
HP	2800 Business Inkjet	360S/311R/B/G/312PS/PR/PB/PG
HP	281 CB E	917R
HP	282 CB E	917G
HP	283 CB E	917FB
HP	284 CB E	917FR
HP	29 NO	925S
HP	290 Color Copier	927S/992C
HP	300 Mini	534S/C
HP	300 XL	534S/C
HP	3000 Deskjet J310	551S/C
HP	301 Mini + XL	551S/C
HP	3050 Deskjet AIO	551S/C
HP	3052 Deskjet All in one	551S/C
HP	3070 Deskjet A	540S/R/B/G/FS
HP	309 Photosmart C A/ B A	540S/R/B/G/FS
HP	310 Deskjet F all in one	586S/587C
HP	310 Photosmart Premium C	540S/R/B/G/FS
HP	3108 Photosmart AIO	917
HP	3150 Photosmart	286S/290C
HP	317 CB EE Photobk	540FSM
HP	318 CB EE Cyan	540BM
HP	3180 Photosmart	286S/291C
HP	319 CB EE Yellow	540GM
HP	3190 Photosmart C	286S/291C
HP	320 Deskjet F AIO	586S/587C
HP	320 Photosmart	292C



Maskinnavn	Modelnummer	Gruppenummer
HP	3210 Photosmart	917
HP	3213 Photosmart	917
HP	322 CB EE XL Photoblack	540FS
HP	3220 Deskjet	324S/325C
HP	323 CB EE XL Cyan	540B
HP	324 CB EE XL Magenta	540R
HP	3240 Deskjet	324S/325C
HP	325 CB EE XL Yellow	540G
HP	325 Deskjet F All in one	586S/587C
HP	325 Photosmart	292C
HP	330 Photosmart	292C
HP	3300 Deskjet	324S/325C
HP	3300 Photosmart AIO	917
HP	331 CB EE	286S
HP	3310 Photosmart AIO	917
HP	332 CB EE 2stk	291C
HP	3320 Deskjet C	324S/325C
HP	3325 Deskjet C	324S/325C
HP	335 Deskjet F All in one	586S/587C
HP	335 Photosmart	292C
HP	336 CB EE 25 ml.	995S
HP	336 NO	285S
HP	337 CB EE 3,5 ml	996C
HP	337 NO	284S
HP	338 CB EE 13,0 ml.	996C
HP	338 NO sort 11 ml.	286S
HP	339 NO sort 21 ml.	288S
HP	340 Deskjet F All in one	586S/587C
HP	3400 Deskjet	324S/325C
HP	342 NO 5 ml	290C
HP	3420 Deskjet C	324S/325C
HP	3425 Deskjet C	324S/325C
HP	343 3-farvet 7 ml.	291C
HP	344 3-farvet 14 ml.	292C
HP	350 CB EE 4,5 ml.	995S
HP	350 Deskjet C + CBI	577S/925C/925F
HP	350 Deskjet F All in one	586S/587C
HP	350 NO XL	995S
HP	351 NO 13,0 ml.	996C
HP	3520 Deskjet	324S/325C
HP	3520 Deskjet All in one	540S/R/B/G
HP	3524 Deskjet E All in one V +W	540S/R/B/G
HP	3525 Deskjet	324S/325C
HP	355 CB EE 4,5 ml.	995S
HP	3550 Deskjet C	324S/325C
HP	3600 Photosmart C	540S/R/B/G/FS
HP	3620 Deskjet C	324S/325C
HP	363 Bk	917S
HP	363 Cyan	917B
HP	363 Magenta	917R
HP	363 Photocyan	917FB
HP	363 Photomagenta	917FR
HP	363 Yellow	917G
HP	364 NO	540
HP	364 NO XL	540
HP	3645 Deskjet C	324S/325C
HP	3647 Deskjet C	324S/325C
HP	3650 Deskjet C	324S/325C



Maskinnavn	Modelnummer	Gruppenummer
HP	3653 Deskjet C	324S/325C
HP	3658 Deskjet C	324S/325C
HP	3668 Deskjet C	324S/325C
HP	3680 Deskjet J AIO	586S/587C
HP	370 Deskjet F All in one	586S/587C
HP	370 Photosmart	292C
HP	3740 Deskjet	324S/325C
HP	3745 Deskjet	324/325C
HP	375 Photosmart	292C
HP	378 Deskjet F All in one	586S/587C
HP	380 Deskjet F All in one	586S/587C
HP	380 Photosmart	292C
HP	3810 Deskjet C	993S/992C
HP	3816 Deskjet C	993S/992C
HP	3820 Deskjet C	993S/992C
HP	3822 Deskjet C	993S/992C
HP	3843 Deskjet	324S/325C
HP	3845 Deskjet	324S/325C
HP	385 Deskjet F All in one	586S/587C
HP	385 Photosmart	291C/292C
HP	388 Deskjet F All in one	586S/587C
HP	390 Deskjet F All in one	586S/587C
HP	3920 Deskjet	586S/587C
HP	394 Deskjet F All in one	586S/587C
HP	3940 Deskjet	586S/587C
HP	40 Officejet V + XI	993S/992C
HP	41 NO	927C
HP	410 CA Photosmart PF	540R/B/G/FS
HP	4110 Photosmart C	284S/291C
HP	4110 PSC All in One	544S/573C
HP	4135 Deskjet F AIO	586S/587C
HP	4140 Deskjet F AIO	586S/587C
HP	4140 Photosmart C	284S/291C
HP	4145 Deskjet D	284S/288S/292C
HP	4150 Deskjet F AIO	586S/587C
HP	4150 Photosmart C	284S/291C
HP	4155 Deskjet D	284S/288S/292C
HP	4160 Deskjet D	284S/288S/292C
HP	4163 Deskjet D	284S/288S/292C
HP	4168 Deskjet D	284S/288S/292C
HP	4172 Deskjet F AIO	586S/587C
HP	4175 Deskjet F AIO	586S/587C
HP	4180 Deskjet F AIO	586S/587C
HP	4180 Photosmart C	284S/286S/291C
HP	4185 Deskjet F AIO	586S/587C
HP	4188 Deskjet F AIO	586S/587C
HP	4190 Deskjet F AIO	586S/587C
HP	4194 Deskjet F AIO	586S/587C
HP	420 Photosmart	292C
HP	4200 Deskjet F serie	534S/C
HP	4210 Deskjet F AIO	534S/C
HP	4211 Officejet AIO	544S/573C
HP	4212 Officejet AIO	544S/573C
HP	4215 Officejet AIO + XI	544S/573C
HP	4219 Officejet AIO	544S/573C
HP	4224 Deskjet F	534S/C
HP	4251 Officejet AIO	544S/573C
HP	4252 Officejet AIO	544S/573C



Maskinnavn	Modelnummer	Gruppenummer
HP	4255 Officejet All in one	544S/573C
HP	4259 Officejet AIO	544S/573C
HP	4260 Deskjet D	995S/996C
HP	4270 Deskjet D	995S/996C
HP	4272 Deskjet F	534S/C
HP	4273 Deskjet F	534S/C
HP	4274 Deskjet F	534S/C
HP	428 Photosmart	291C/292C
HP	4280 Deskjet D	995S/996C
HP	4280 Deskjet F AIO	534S/C
HP	4283 Deskjet F	534S/C
HP	4292 Deskjet F	534S/C
HP	4293 Deskjet F	534S/C
HP	4294 Deskjet F	534S/C
HP	4311 Officejet AIO	324S/587C
HP	4312 Officejet AIO	324S/587C
HP	4314 Officejet AIO	324S/587C
HP	4315 Officejet AIO + V	324S/587C
HP	4317 Officejet AIO + XI	324S/587C
HP	4319 Officejet AIO	324S/587C
HP	4352 Officejet AIO	324S/587C
HP	4353 Officejet AIO	324S/587C
HP	4355 Deskjet AIO	586S/587C
HP	4355 Officejet AIO	324S/587C
HP	4357 Officejet AIO	324S/587C
HP	4359 Officejet AIO	324S/587C
HP	4360 Deskjet D	995S/996C
HP	4380 Deskjet D	995S/996C
HP	4382 Deskjet D	995S/996C
HP	4383 Deskjet D	995S/996C
HP	4384 Deskjet D	995S/996C
HP	4385 Deskjet D	995S/996C
HP	4388 Deskjet D	995S/996C
HP	4440 Deskjet F	534S/C
HP	4470 Deskjet F AIO	534S/C
HP	4472 Deskjet F AIO	534S/C
HP	4480 Deskjet F AIO	534S/C
HP	4480 Photosmart C AIO	995S/996C
HP	4492 Deskjet F AIO	534S/C
HP	45 NO	927S
HP	45 Officejet R	927S/928C
HP	450 Deskjet CI + CBI	544S/573C
HP	4500 Officejet	459S/C
HP	4515 Officejet XI	586S/587C
HP	4524 Officejet J	459S/C
HP	4535 Officejet J	459S/C
HP	4580 Deskjet F AIO	534S/C
HP	4580 Officejet J	459S/C
HP	4580 Photosmart C AIO	995S/996C
HP	4583 Deskjet F AIO	534S/C
HP	4599 Photosmart C AIO	995S/996C
HP	460 Deskjet Mobil + CB	286S/292C
HP	4600 Officejet Series	459S/C
HP	4600 Photosmart series	534S/C
HP	4624 Officejet J	459S/C
HP	4635 Photosmart C AIO	534S/C
HP	4640 Photosmart C AIO	534S/C
HP	4650 Photosmart C AIO	534S/C



Maskinnavn	Modelnummer	Gruppennummer
HP	4660 Officejet J	459S/C
HP	4680 Officejet J	459S/C
HP	4680 Officejet J	459S/C
HP	4680 Photosmart C AIO	534S/C
HP	4683 Photosmart C AIO	534S/C
HP	4685 Photosmart C AIO	534S/C
HP	470 Officejet H Mobil	286S/292C
HP	470 Photosmart	292C
HP	475 Photosmart	291C/292C
HP	4780 Photosmart C AIO	534S/C
HP	49 NO	925C
HP	4902 C AE Bk 1K	282S
HP	4906 C AE Bk 2.2K	282S
HP	4907 C AE Cyan	282B
HP	4908 C AE Magenta	282R
HP	4909 C AE Yellow	282G
HP	500 Officejet	925S/C
HP	500 Officejet PSC	993S/928C
HP	510 Photosmart Estation	540R/B/G/FS
HP	5100 Deskjet	544S/573C
HP	5110 All in one	993S/992C
HP	5145 Photosmart D	288S/292C
HP	5150 Deskjet	544S/573C
HP	5155 Photosmart D	288S/292C
HP	5156 Photosmart D	288S/292C
HP	5160 Photosmart D	288S/292C
HP	51629 A + D + G	925S
HP	51641 A + D + G	927C
HP	51645 A+ D + G	927S
HP	51649 A + D + G	925C
HP	5168 Photosmart D	288S/292C
HP	5180 Photosmart C AIO	917
HP	5240 Photosmart C AIO	995S/996C
HP	5250 Photosmart C AIO	995S/996C
HP	5280 Photosmart C AIO	995S/996C
HP	5300 Photosmart C	540S/R/B/G/FS
HP	5324 Photosmart C	540S/R/B/G/FS
HP	5380 Photosmart C	540S/R/B/G/FS
HP	5383 Photosmart C	540S/R/B/G/FS
HP	5390 Photosmart C	540S/R/B/G/FS
HP	5420 Deskjet	285/290CP
HP	5432 Deskjet	285/290CP
HP	5440 Deskjet	285S/290C
HP	5442 Deskjet	285S/290C
HP	5443 Deskjet	285S/290C
HP	5460 Photosmart D	540S/R/B/G/FS
HP	55 Officejet G	927S/992C
HP	5505 Officejet	544S/573C
HP	5510 Officejet	544S/573C
HP	5510 Photosmart	540S/R/B/G/FS
HP	5514 Photosmart	540S/R/B/G/FS
HP	5515 Officejet	544S/573C
HP	5515 Photosmart	540S/R/B/G/FS
HP	5520 Photosmart	540S/R/B/G/FS
HP	5550 Deskjet C	544S/573C
HP	5551 Deskjet C	544S/573C
HP	5552 Deskjet C	544S/573C
HP	5560 Deskjet D	534S/C



Maskinnavn	Modelnummer	Gruppenummer
HP	5563 Deskjet D	534S/C
HP	5568 Deskjet D	534S/C
HP	56 NO	544S
HP	561 CH EE	551SM
HP	5610 Officejet	544S/587C
HP	562 CH EE	551CM
HP	563 CH EE	551S
HP	564 CH EE	551C
HP	5652 Deskjet C	544S/573C
HP	5655 Deskjet C	544S/573C
HP	57 NO	573C
HP	5740 Deskjet	288S/292C
HP	5743 Deskjet	288S/292C
HP	5780 Officejet J AIO	995S/996C
HP	5785 Officejet J AIO	995S/996C
HP	5830 Deskjet	324S/325C
HP	5850 Deskjet	544S/573C
HP	590 Officejet	925S/C
HP	5940 Deskjet	284S/288S/292C
HP	5943 Deskjet	284S/288S/292C
HP	60 Officejet K	927S/992C
HP	600 Deskjet + C	925S/C
HP	600 Deskwriter	923S/925C
HP	610 Deskjet C	923S/925C
HP	6110 Officejet PSC	544S/573C
HP	612 Deskjet C	923S/925C
HP	6120 Deskjet C	927S/992C
HP	6122 Deskjet C	927S/992C
HP	6127 Deskjet C	927S/992C
HP	615 Deskjet C	923S/925C
HP	6150 Photosmart C AIO	917
HP	6154 Photosmart C AIO	917
HP	6160 Photosmart D AIO	917
HP	6163 Photosmart D AIO	917
HP	6170 Photosmart C AIO	917
HP	6175 Photosmart C AIO	917
HP	6180 Photosmart C AIO	917
HP	6183 Photosmart C AIO	917
HP	6185 Photosmart C AIO	917
HP	6188 Photosmart C AIO	917
HP	6190 Photosmart C AIO	917
HP	6200 Officejet AIO	286S/292C
HP	6210 Officejet AIO	286S/292C
HP	6270 Photosmart C AIO	917
HP	6280 Photosmart C AIO	917
HP	6285 Photosmart C AIO	917
HP	630 Deskjet C	923S/925C
HP	6300 Photosmart C	540R/B/G/FS
HP	6310 Officejet AIO	284S/286S/291C
HP	6313 Officejet	288S/291C
HP	6324 Photosmart C	540S/R/B/G/FS
HP	635 Officejet	923S/925C
HP	6380 Photosmart C	540S/R/B/G/FS
HP	640 CC EE Mini	534SM
HP	640 Deskjet C	923S/925C
HP	641 CC EE XL	534S
HP	6410 Officejet J	995S/996C
HP	643 CC EE Mini	534CM



Maskinnavn	Modelnummer	Gruppennummer
HP	644 CC EE XL	534C
HP	65 Officejet T + R	927S/928C
HP	6500 Officejet series	391S/R/B/G
HP	6510 Photosmart E All in one	540S/R/B/G
HP	653 CC AE 4ml Black	459S
HP	654 CC AE XL 14 ml Black	459S
HP	6540 Deskjet	288S/292C
HP	6543 Deskjet	288S/292C
HP	656 CC AE Color	459C
HP	656 Deskjet C	923S/925C
HP	6578 C	992C
HP	660 Deskjet C	925S/C
HP	660 Deskwriter C	925S/C
HP	661 CN EE Setup Sort	540S/R/B/G/FS
HP	6615 C	993S
HP	6620 Deskjet	288S/292C
HP	6625 C	572C
HP	6628 C	577S
HP	6656 C	544S
HP	6657 C	573C
HP	6658 C	573FP
HP	670 Deskjet C	925S/C
HP	6700 Officejet E	674S/R/B/G
HP	684 CN EE 12 ml sort OEM	540S/R/B/G/FS
HP	6840 Deskjet	288S/292C
HP	6843 Deskjet	288S/292C
HP	690 Deskjet C + Plus	925S/C/F
HP	693 Deskjet C	925S/C/F
HP	694 Deskjet S	925S/C/F
HP	6940 Deskjet	284S/288S/292C
HP	695 Deskjet C	925S/C/F
HP	697 Deskjet C	925S/C/F
HP	6980 Deskjet	284S/288S/292C
HP	700 Officejet	925S/C
HP	700 PSC	993S/992C
HP	7000 Officejet series	391S/R/B/G
HP	710 Deskjet C	927S/928C
HP	710 Officejet C + Pro	925S/C/F
HP	7100 Officejet K	284S/288S/292C
HP	7100 Serie	917
HP	7145 Photosmart D AIO	917
HP	7150 Photosmart C	544S/573C
HP	7150 Photosmart C AIO	917
HP	7155 Photosmart D AIO	917
HP	7160 Photosmart D AIO	917
HP	7168 Photosmart D AIO	917
HP	7170 Photosmart D AIO	917
HP	7177 Photosmart D AIO	917
HP	7180 Photosmart C AIO	917
HP	7183 Photosmart C AIO	917
HP	7186 Photosmart C AIO	917
HP	7188 Photosmart C AIO	917
HP	7190 Photosmart C AIO	917
HP	720 Deskjet C	927S/928C
HP	720 Officejet PSC	925S/C/F
HP	7210 Officejet	288S/292C
HP	722 Deskjet C	927S/928C
HP	7260 Photosmart	544S/573C



Maskinnavn	Modelnummer	Gruppenummer
HP	7280 Photosmart C AIO	917
HP	7310 Officejet	288S/292C
HP	7313 Officejet	288S/292C
HP	7345 Photosmart C	544S/573C
HP	7345 Photosmart D	917
HP	7350 Photosmart C	544S/573C
HP	7355 Photosmart D	917
HP	7360 Photosmart D	917
HP	7368 Photosmart D	917
HP	7410 Officejet	288S/292C
HP	7413 Officejet	288S/292C
HP	7450 Photosmart	544S/573C
HP	7460 Photosmart D	917
HP	750 Designjet C + Plus	927S/527R/B/G
HP	750 Officejet PSC + I	993S/992C
HP	7500 Officejet A AIO	391S/R/B/G
HP	7510 Photosmart	540S/R/B/G/FS
HP	7550 Photosmart C	544S/573C
HP	7560 Photosmart D	540S/R/B/G/FS
HP	7660 Photosmart	544S/573C
HP	7662 Photosmart	544S/573C
HP	7760 Photosmart	544S/573C
HP	7762 Photosmart	544S/573C
HP	78 NO	992C
HP	7850 Photosmart	286S/291C
HP	7960 Photosmart	544S/573C
HP	80 Officejet K	927S/992C
HP	800 Deskjet C	927S/928C
HP	8000 Officejet Pro	282S/R/B/G
HP	8050 Photosmart	284S/288S/292C
HP	810Deskjet C	993S/928C
HP	8110 Photosmart C AIO	917
HP	812 Deskjet C	993S/928C
HP	815 Deskjet C	927S/928C
HP	8150 Photosmart	288S/292C
HP	8153 Photosmart	288S/292C
HP	8180 Photosmart C	917
HP	820 Deskjet CXI	927S/C
HP	825 Deskjet C	993S/572C
HP	8250 Photosmart	917
HP	830 Deskjet C	927S/928C
HP	8350 Photosmart Pro B	284S/292C
HP	840 Deskjet C	993S/572C
HP	841 Deskjet C	993S/572C
HP	842 Deskjet C	993S/572C
HP	843 Deskjet C	993S/572C
HP	845 Deskjet C	993S/572C
HP	8450 Photosmart	288S/292C
HP	8453 Photosmart	288S/292C
HP	85 Officejet G	927S/992C
HP	850 Deskjet C	927S/C
HP	8500 Officejet Pro	282S/R/B/G
HP	855 Deskjet C	927S/C
HP	8550 Photosmart B	540S/R/B/G/FS
HP	8600 Officejet Pro	282S/R/B/G
HP	870 Deskjet CXI	927S/C
HP	8719 C EE	917S 17 ml
HP	8721 C EE	917S 6 ml



Maskinnavn	Modelnummer	Gruppenummer
HP	8727 C	324S
HP	8728 C	325C
HP	8750 Photosmart	288S/292C
HP	8765 C EE	286S
HP	8766 C EE	291C
HP	8767 C EE	288S
HP	8771 C EE Cyan	917B
HP	8772 C EE Magenta	917R
HP	8773 C EE Yellow	917G
HP	8774 C EE Photocyan	917FB
HP	8775 C EE Photomagenta	917FR
HP	880 Deskjet C	927S/928C
HP	890 Deskjet C	927S/928C
HP	895 Deskjet C + CXI	927S/928C
HP	9004 C EE 2-stk	288S
HP	9005 C EE 2-stk	292C
HP	901 3-farvet	459C
HP	901 NO black	459S
HP	916 Deskjet C	993S/992C
HP	920 Deskjet C	993S/992C
HP	925 FAX XI	923S
HP	927 CG EE R+B+G	540R/B/G
HP	930 Deskjet C	927S/992C
HP	932 Bk	674S
HP	933 C/M/Y	674R/B/G
HP	935 Deskjet C	927S/992C
HP	9351 C AE	586S
HP	9352 C AE	587C
HP	9361 C EE 5 ml	290C
HP	9362 C EE	285S
HP	9363 C EE	292C
HP	9364 C EE	284S
HP	94 sort 11 ml.	286S
HP	940 Deskjet C	993S/992C
HP	940 NO XL Bk	282S
HP	940 NO XL Cyan	282B
HP	940 NO XL Magenta	282R
HP	940 NO XL Yellow	282G
HP	948 Deskjet C	923S/925C
HP	95 3-farvet 7 ml.	291C
HP	95 Officejet G	927S/992C
HP	950 Bk	972S
HP	950 Deskjet C	927S/992C
HP	950 Officejet PSC	993S/992C
HP	951 C/M/Y	972R/B/G
HP	959 Deskjet C	927S/992C
HP	96 sort 21 ml.	288S
HP	960 Deskjet CXI	927S/992C
HP	9650 Deskjet	544S/573C
HP	9670 Deskjet	544S/573C
HP	9680 Deskjet	544S/573C
HP	97 3-farvet 14 ml.	292C
HP	970 Deskjet C + CXI	927S/992C
HP	972 CD AE 0.7K	391B
HP	973 CD AE 0.7K	391R
HP	974 CD AE 0.7K	391G
HP	975 CD AE 1.2K	391S
HP	980 Deskjet C	927S/992C



Maskinnavn	Modelnummer	Gruppenummer
HP	9800 Deskjet	288S/292C
HP	990 Deskjet CXI	927S/992C
HP	995 Deskjet C	927S/992C

**Bogstavkode i forbindelse med gruppenummer**

S	Sort (Black)
R	Rød (Magenta)
B	Blå (Cyan)
G	Gul (Yellow)
C	Color
FB	Foto blå (Photo Cyan)
FR	Foto rød (Photo Magenta)
FS	Foto sort (Photo Black)
GY	Grå (Grey)
HC	High Capacity
PC	Printhoved Color
PB	Printhoved Blå (Cyan)
PG	Printhoved Gul (Yellow)
PR	Printhoved Rød (Magenta)
PS	Printhoved Sort (Black)

Husk at du kan ringe til os hvis du har spørgsmål

Mandag - Fredag 09:00-17:00

Tlf:

36 46 88 44